
2x4 Plus Pendant Collection

Installation and Product Guide 36", 48", and 60" Pendants



AlexAllen Studio

CAUTION:

Electric shock risk. Turn off electrical power at breaker before beginning installation. We recommend this product be installed by a qualified electrician only.


INSTALLATION INSTRUCTIONS

- (1) Attach Ceiling Plate to ceiling Junction Box with junction
- (2) Unscrew the Cable Holders from Threaded Inserts on the pendant. Feed one Suspension Cable through the base of the Cable Holder till it rests on the end stopper. Screw the Cable Holder back into the Threaded Insert, locking the end stopper in place. Repeat for all Cable Holders. See 'Diagram A' on back of instruction booklet for more detail.
- (3) Feed the four Suspension Cables through the holes in the bottom of the Canopy and into the Cable Grippers in the Ceiling Plate. Continue feeding Suspension Cables through the cable grippers until the fixture is level and at the desired height. Trim the end of the cable with approved cable cutters. See 'Diagram B' box '1' on back of instruction booklet for more detail.
- (4) Feed the end of the **Power Cord** into the large center hole in Canopy and trim, leaving some extra length to connect to driver. 'Diagram B' box '2' on back of instruction booklet for more detail.
- (5) Connect Power Cord electrical wire ends to LED Driver output (Red, Blue). Connect the driver input cables to the line voltage input. 24V DC ONLY! Red Wire: LED+. Black Wire: LED-. Purple Wire: Dim+. Pink Wire: Dim-.
- (6) Slide the Canopy up the Suspension Cables to the ceiling and secure it using the two Set Screws. See Diagram 'A' box '3' on back of instruction booklet for more detail.
- (7) Position Strain Relief onto Power Cord at the desired length and close with pliers. Push Strain Relief into second hole on Feed Side Canopy to finish installation.

Flexible LED Module (>60,000 Hour Lifespan) Universal Voltage 120V-277V, 50Hz/60Hz



INSTALLATION DIAGRAMS



CARE INSTRUCTIONS

For removing oils from metal surfaces after handling, or for removing moisture, grease, or dirt, wipe or rub lightly with a dry microfiber or cotton cloth.

Do not use any abrasive or acidic household cleaning products on product surfaces.


For the best maintenance of the product, protect against sunlight, heat, or any other natural elements.

DIMMER COMPATIBILITY

LUTRON:	CONT.
CASETA WIRELESS PD-6WCL	DS710
DIVA CL DVCL-153P-WH	DD710
DIVA ELV DVELV-303P	
DIVA 0-10V DVSTV	CRESTRON:
DIVA 0-10V DVTV	CLW-DIMSWEX-P
HOME WORKS HQRD-6A	P-DIMEX
HOME WORKS HQRD-6NA	GLX-DIM6
MRF2-6ELV-12O-WH	GLXX-2DIM8
MAESTRO MRF2-6ELV-120-WH	CLW-DELVEX-E
MAESTRO RF RRA-6D	CLW-DELVEX-P
MAESTRO RF RRA-6NA	CLX-2DIMFLV8
MAESTRO RF RRA-6ND	DIN-4DIMFLV4
MAESTRO MAELV-600	CLS-EXP-DIMFLV
MAESTRO MSCELV-600M	GLX-DIMFLV8
MAESTRO CL MACL-153MH	SELV-300P
MAESTRO IR MIRELV-600	CLS-C6
MAESTRO WIRELESS MRF2-6ELV-120	CLS-C6M
NOVA T NTELV-600-WH	CLS-C6EX
NOVA NVELV-600-WH	CLS-C6MEX
NOVA T NTELV-300	CLS-C6MRF
SKYLARK SELV-600-WH	CLS-C6RF
SKYLARK CONTOUR CTELV-303P	CLS-EXP-DIM
VIERTI VTELV-600-XXX	CLS-EXP-DIMU
	CLX-1DIM4
LEVITON:	CLX-1DIM8
6615	CLX-2DIM2
6672	CLX-2DIM8
6674/IPL06	CLX-1DELV4
IPEO4	DIN-1DIM4
IPIO6	DIN-1DIMU4
VP106	CLW-DIMEX-E
VPE04	CLW-DIMEX-P
VPM06	CLW-DIMSWEX-E
VREO4	
VRM10	FEIT
IP710	BPMIMSMART/2

INSTALLATION DIAGRAMS - CONTINUED


Diagram A



1: Feed one Suspension Cable through the base of the Cable Holder till it rests on the end stopper.

2/3: Screw the Cable Holder back into the Threaded Insert, locking the end stopper in place.

Diagram B



1: Attach Ceiling Plate to ceiling Junction Box with junction box screws. Feed the four Suspension Cables through the holes in the bottom of the Canopy and into the Cable Grippers in the Ceiling Plate.

- 2: Feed the end of the Power Cord into the large center hole in Canopy and trim, leaving some extra length to connect to driver.
- **3:** Slide the Canopy up the Suspension Cables to the ceiling and secure it using the two Set Screws. Position Strain Relief onto Power Cord at the desired length and close with pliers. Push Strain Relief into second hole on Feed Side Canopy to finish installation.

AlexAllen Studio LLC
T: +1 (917) 909-0405
info@alexallenstudio.com
www.alexallenstudio.com

Version: December 1, 2024